

Tarkett

**Safetred Dimension PU, Safetred Dimension Wood PU,
Safetred Universal PU, Safetred Universal Tile PU,
Safetred Universal Plus PU, Safetred Spectrum PU,
Safetred Spectrum Tile PU, Safetred Wood/Natural**

March 2012

To help protect your floorcovering from varying levels of traffic and also as the first defence against the weather, we strongly recommend that barrier mats be installed at entry points to the building to limit the amount of wet and dry soiling. If maintained correctly, these barrier mats should limit the transfer of foot borne contamination and make the daily cleaning and maintenance programme even easier.

Polish or maintainers should never be applied to Safetred, as this would reduce the effectiveness of the surface profile and slip resistance. The unique PUR factory applied surface treatment assists with the ease of maintenance.

For commercial to heavy commercial applications mechanical maintenance is considered essential on a regular ongoing basis.

Initial Treatment

1. Allow at least 5 days from the completion of the installation of the floorcovering, prior to carrying out any wet cleaning.
2. Ensure that all trace of adhesive is removed from the surface of the floorcovering.
3. Clean floor area with a soft broom.
4. Depending on the level of site soiling after the installation is complete, it may be necessary to scrub the floor clean, prior to adopting the daily maintenance regime. Please find the following options.
 - a) Mop clean with diluted **Johnson Diversey Carefree Stride 1000 or an equivalent** neutral detergent with a pH7.
 - b) Scrub the surface of the Safetred using a contra rotating cylindrical machine, rotary scrubber or a scrubber-dryer standard speed machine fitted with a **medium brush**.
 - c) Rinse area clean with hot water and allow to dry completely.

Routine Maintenance

Non-Mechanical Method

1. Clean floor area with a soft broom.
2. Spray apply a solution of Stride 1000 diluted as per the manufactures recommendation. A pump-up spray will allow for even distribution and economy of the cleaning solution. (Carefree Stride 2000 should be used on areas that are heavily soiled or greasy. Leave to stand for 5-10 minutes then agitate with a deck scrubber).
3. Rinse area clean with hot water and allow to dry completely (if required).

Tarkett

**Safetred Dimension PU, Safetred Dimension Wood PU,
Safetred Universal PU, Safetred Universal Tile PU,
Safetred Universal Plus PU, Safetred Spectrum PU,
Safetred Spectrum Tile PU, Safetred Wood/Natural**

March 2012

Mechanical Method

1. Clean floor area with a soft broom.
2. Spray apply a solution of Stride 1000, diluted as per the manufactures recommendation. A pump-up spray will allow for even distribution and economy of the cleaning solution. (Carefree Stride 2000 should be used on areas that are heavily soiled or are greasy. Leave to stand for 5-10 minutes).
3. Scrub the surface of the Safetred using a contra rotating cylindrical machine, rotary scrubber or a scrubber-dryer standard speed machine fitted with a **medium brush**.
4. Rinse area clean with hot water and allow to dry completely.

Lime scale may form occasionally in wet areas. These deposits can be easily removed by using an acidic cleaner (pH 2 – 4). Rinse thoroughly after use with clean water.