MAINTENANCE INSTRUCTIONS

TARKETT TILT, STARFLOOR CLICK 30 AND ID INSPIRATION CLICK



To help protect your floorcovering from varying levels of traffic and also as the first defence against the weather, we strongly recommend that barrier mats be installed at entry points to the building to limit the amount of wet and dry soiling. If maintained correctly, these barrier mats should limit the transfer of foot borne contamination and make the daily cleaning and maintenance programme even easier.

Polish or maintainers should not to be applied to the surface of Tilt, Starfloor and I.D. products, as the unique PUR factory applied surface treatment removes their necessity.

Initial Treatment

- 1. Allow at least 5 days from the completion of the installation of the floorcovering, prior to carrying out any wet cleaning.
- 2. Ensure that all trace of adhesive is removed from the surface of the floorcovering.
- 3. Clean floor area with a vacuum, soft broom or preferably a dust control mop.
- 4. Depending on the level of site soiling after the installation is complete, it may be necessary to scrub the floor clean, prior to adopting the daily maintenance regime. Please find the following options.
 - a) Mop clean with diluted SYR Scrubclean Solution neutral PH detergent * or an equivalent neutral detergent with a pH7.
 - b) Scrub floor clean with diluted SYR Scrubclean Solution neutral PH detergent * using a standard-speed rotary machine (150 250rpm) fitted with a **tan pad** or scrub with a scrubber dryer (combination machine) fitted with a **tan pad**.
 - c) Scrub floor clean with diluted SYR Scrubclean Solution neutral PH detergent * using a standard-speed rotary machine (150 250rpm) fitted with a **red pad** or scrub with a scrubber dryer (combination machine) fitted with a **red pad**. If the surface is dull, dry burnish with an ultra high-speed rotary machine (best results 1000rpm) fitted with a **white pad**.

Routine Maintenance

Non-Mechanical Method



- 1. Clean floor area with a broom or preferably a dust control mop.
- 2. **If soiled:** Damp mop the area clean with the SYR Scrubclean system with diluted Scrubclean Solution neutral PH detergent *. Use a SYR Palomine pad to remove heavier soiling.

It is important to ensure that only the smallest amount of moisture is deposited onto the floorcovering when cleaning, so that the floorcovering surface will dry within 15 - 20 seconds.

Mechanical Method



- 1. Clean floor area with a vacuum, broom or preferably a dust control mop.
- 2. **If soiled:** Spray clean with diluted SYR Scrubclean Solution neutral PH detergent *, using an ultra-high speed rotary machine fitted with a **white pad.**





TARKETT TILT, STARFLOOR CLICK 30 AND ID INSPIRATION CLICK

2015

Periodic Maintenance



- 1. Clean floor area with a vacuum, broom or preferably a dust control mop
- Scrub floor clean with diluted SYR Scrubclean Solution neutral PH detergent *. (or for heavily soiled or greasy areas SYR CS3 *) using a standard-speed rotary machine (150 250rpm) fitted with a **tan pad** or scrub with a scrubber dryer (combination machine) fitted with a **tan pad.** If the surface is dull, dry burnish with an ultra-high-speed rotary machine (best results 1000rpm) fitted with a **white pad.**
- 3. Depending on the location, it may necessary to occasionally scrub the floor clean with diluted SYR Scrubclean Solution neutral PH detergent * using a standard-speed rotary machine (150 250rpm) fitted with a **red pad** or scrub with a scrubber dryer (combination machine) fitted with a **red pad**. Finally dry burnish with an ultra-high-speed rotary machine (best results 1000rpm) fitted with a **white pad**.

Dry burnishing is an efficient method for limiting scuffmarks and also restores the floors surface (if light scratching has become visible). It is best to dry burnish immediately after the floorcovering has been machine scrubbed. Dry burnishing greatly reduces renewed soiling. Use an ultra high-speed rotary machine (best results 1000rpm) fitted with a **red pad**.

Cleaning & Maintenance

Stairs - Non-Mechanical



Mechanical Method

<u> Stairs – Mechanical (For</u> Larger Applications)



- 1. Clean risers with a broom or dust control cloth.
- 2. Clean treads by vacuuming or use a soft broom to sweep across the width of the stair.

Damp mop the area clean with the SYR Scrubclean system and diluted Scrubclean Solution neutral PH detergent * (or for heavily soiled or greasy areas SYR CS3 *) using a double bucket system, use a SYR Palomine pad to remove heavier soiled areas.

- 1. Clean risers with a broom or dust control cloth.
- 2. Clean treads by vacuuming or use a soft broom to sweep across the width of the stair.
- 3. The use of a small scrubbing machine such as a Primaster Combi 2 in 1 fitted with a white or tan pad, with diluted solution of SYR Scrubclean Solution neutral PH detergent *. (or for heavily soiled or greasy areas SYR CS3 *) can make the maintenance of Stair applications simpler.

(* See the attached details below).





Existing cleaning products and methods are no longer fit for purpose. With this new integrating family of products SYR Tic will correct long standing faults related to safety and cleaning. Quality training will be simplified and lead to consistency which in turn will produce huge levels of cost reduction and customer satisfaction.





Contact Us | Email: safefloors@syrclean.com Tel: +44(0)1384 421215 Web: www.syrtic.com

