

Tarkett iQ One is a new type of resilient homogeneous flooring manufactured of "non pvc" material. This means that special attention must be taken to certain installation details. [These are here written in blue and italic text.](#)

Note: This is a guide only, for all requirements and installation instruction refer to [AS 1884-2012 Floor coverings - Resilient sheet and tiles - Installation practices](#)

CONDITIONS AND REQUIREMENTS

- The subfloor must be clean, dry and free from cracks. Dust and contaminants that could prevent adhesion, such as patches of paint, oil, etc., must be removed. Note that asphalt, oil spillage, impregnation agents, pen marks, etc., can cause discoloration. Damp proofing to be carried out according to local building standards. Where required an effective damp proof membrane must be incorporated in the subfloor. Check for dampness in ground supported floors, floors above boiler rooms, floors with underfloor heating or containing high temperature pipework etc.
- **When installing this product on concrete subfloors that do not include damp-proofing, the moisture content measured in terms of relative humidity must not be higher than 70-75% (For all subfloor preparation requirements please refer to AS 1884-2012 Floor coverings - Resilient sheet and tiles - Installation practices). Or less than 2% with CM (Carbide Method).**
- Where pipes are laid in the floor they should be arranged so that the flooring material is not continuously subjected to a temperature above 27°C, otherwise there may be discoloration and/or other alterations of the material.
- Extra special care must be taken regarding installations on surfaces where significant temperature changes can be expected, for example, floors exposed to strong sunlight, as adhesion strength and subfloor treatment may be heavily stressed.
- Floor boards and similar substrates should have a moisture content of max 8% (equivalent to 40% RH at +20°C), so that any subsequent movements cannot cause damage.

PREPARATION

- Dust and loose particles must be thoroughly removed. Highly absorbent or variably absorbent substrates should be sealed with suitable primer. The primed surface must be completely dry before laying commences.
- **Levelling compound with a minimum surface tensile strength of 0,5 MPa is required. For heavy trafficked areas is levelling compound corresponding to 1,0 MPa recommended.**
NOTE: Discolouration can occur when using two-parts polyester compounds if they are mixed incorrectly and/or insufficiently. Do not mix directly on the substrate.

- Use only a lead pencil for marking. Note that any marks made with felt-tipped pens, permanent and non permanent ink markers, ball point pens etc. can cause discoloration due to migration.
- If material from several rolls is used, they should have the same manufacturing serial numbers and be used in consecutive order.
- Prior to laying, allow the material, adhesive and subfloor to reach room temperature, i.e. a temperature of at least 18°C. The relative air humidity should be 30-60%. **Rolls must be stored indoors.**
- **The rolls should be stored upright.** Any faults in the material must be reported immediately to your nearest sales office. Always quote the colour and roll numbers, which are stated on the label.
- **Avoid sharp creasing or folding's when handling sheets. If white lines occurs in the surface, heat gently with a heat gun.**


INSTALLATION

- Installation should be carried out at room temperature between 18°C to 26°C. Subfloor temperature must be at least 15°C. The relative air humidity in the premises should be 30-60%. Maintain same temperature and humidity for at least 72 hours after installation.
- Cut the sheets to length and, if possible, lay them out to acclimatise prior to laying. This is particularly important for longer lengths.
- **The sheets are fully adhered with an adhesive approved for Tarkett iQ One. See the adhesive manufacturer's instruction regarding coverage, open time etc.**
- The assembly time depends on the type of substrate, its absorbency, the temperature and air humidity in the premises.
- **Sheets must be installed so that colour differences are avoided. Reverse sheets whenever possible.**
- Rub the face surface down thoroughly to ensure that the floor covering makes good contact with the adhesive and that all air is expelled. Make sure that the tool used for rubbing down the floor covering does not scratch the surface. A broom is not suitable for this purpose. Use a floor roller (approx. 65 kg) and roll crosswise over the floor.


If any doubts or clarifications should be needed, please contact your local Tarkett representative for further information.

FITTING, COVING AND CORNERS


- The flooring is covered approximately 150 mm up the wall. If wall covering less than 2mm in thickness is to be installed, then it should overlap the wall base by at least 30 mm. For best results, the thickness of the wall base is leveled out before installation of the wall covering so that a smooth juncture is obtained, use a water-resistant leveling compound.
- Within 0,5 m radius from floor drains etc. seams are not recommended.




Using a straight edge and pencil, mark at a height of about 10 cm (approx. 4 in.) all walls where the flooring will be covered. Apply the adhesive on the walls up to the marked line, using a fine-notched trowel. Spread some of the adhesive out onto the floor, as shown in the picture.



While the adhesive becomes tacky, the sheets are cut. The sheets should be cut longer than the room length to allow sufficient material for coving. When a sheet fits the width of the room, mark a cross mark on the bottom of the material and the subfloor to indicate the center. This will help you to place the sheet in its exact position. The cross marks are to coincide at installation.




When the width of the room exceeds the sheet width (more than one piece has to be installed to cover the area), mark a line on the floor parallel to the longitudinal wall at a distance equivalent to 12 cm (about 4 1/2 in.) less than the sheet width. Mark the room's center on this line. On the bottom of each sheet, mark their center. The cross marks on the subfloor and sheets shall coincide at installation.




Fold back and loosen the sheets covering half of the floor area. Apply the adhesive on the subfloor with a fine-notched trowel. Use a soft brush around drains and hard-to-reach areas. Around and inside drains, please see drain manufacturers recommendation.




When coving, use a **Tarkett Hockey Stick** (art. no. 1258003) or similar tool to press the material firmly into the juncture between the floor and wall. Do not use a so called **Corner Roller**.




When fitting in-corners, make a cut in the excess material starting about 5 mm (about 1/4 in.) above the floor in the corner. If the material has to be heated before folding, heat the area between the sheet and the wall. This provides better contact between the sheet and adhesive.



Press the material firmly into the corner with a **Tarkett Hockey Stick** or similar tool.




The corner seam shall be placed on one of the walls at a 45-degree angle.




When fitting an out-corner, the sheet is folded against the corner and cut about 5 mm (1/4 in.) from the floor. The guidelines in the picture show the corner on the sheet and the position of the cut at about a 45-degree angle. Then a diagonal cut is made as shown.


If any doubts or clarifications should be needed, please contact your local Tarkett representative for further information.




To glue the triangle-shaped piece more simply and securely, cut a groove on the back of the triangle with Tarkett Corner Knife. The depth of the groove shall be no deeper than half of the sheet thickness.



The triangle can now be folded and placed on the corner. It will overlap the covered floor. Cut through the overlapping material to make a tight fit.




All seams on floor and covering must be grooved before welding.



Use a hot-air gun for welding with thread at in-corners and out-corners. Tarkett Speed Welding Nozzle is specially designed for this purpose. For a perfect job, the Tarkett Swan Neck is required to effectively seal all seams nearest to the floor.


N.B. Prior to sealing in the corner, make sure that the PUR reinforcement is completely removed from the surface

FITTING AROUND PIPES AND FLOOR DRAINS




Around pipes by walls, cut the sheet and press it against the pipe to form a collar. In tight or cramped areas between pipes and walls, cut as shown by the dotted line. If a cover is required, do the following:

1) If you make a cover out of floor material, fit it against the pipe with adhesive. Weld the seams together using the Tarkett Swan Neck.




2) Prefabricated covers are applied according to the manufacturer's instructions. Seam sealer or sealing compound approved for this purpose, can be used for an extra tight fit around pipes.




Around drain pipes, fold the sheet against the pipe and mark a line on the material where the centre of the pipe is. Cut an evenly round hole without notches along the cut, about 25 mm (about 1 in.) smaller than the diameter of the pipe.

Heat the material carefully and squeeze it gently over the pipe. Small stretch marks in the material's surface will occur but this does not affect the product's functionality. Try with a leftover piece before assembly begins.




Alternatively is a prefabricated cover used.

If any doubts or clarifications should be needed, please contact your local Tarkett representative for further information.




Around flush drain openings, heat the sheet and mark the location of the drain using a clamp ring. Then cut a small hole in the centre of the drain within the mark. Heat the flooring and press the clamp ring down into the edge of the drain. When using an adjustable clamp ring, make sure it fits tightly. Trim the material around the perimeter of the ring.
Alternatively; use cutting tool as per recommendation from the drain manufacturer.
Always ask for complete instructions from the drain manufacturer!

WELDING



The sheets are heat welded. Do not weld until the adhesive has bonded completely. The joints are grooved to about $\frac{3}{4}$ of the thickness.


Use an electric grooving machine equipped with a dust bag. For smaller areas use a suitable cutting tool. Due to the composition of this product, triangular shaped handgrooving tools or similar are not recommended. Sweep accurately to remove any dust or residues from the groove.



Weld with hot-air and Tarkett Speed Welding Nozzle. Carry out a test welding on a leftover piece before commencing work, to adjust speed and temperature.

It is recommended to use a slightly higher welding temperature compared to vinyl welding rod.

TRIMMING



IMPORTANT: Both rough cut and fine trimming must be carried out while the welding rod is still lukewarm.

Start trimming where you began welding. All trimming of welding thread is recommended in two steps: rough and fine trimming.

INSPECTION

- The work must be completed with an inspection. Ensure that the newly laid flooring is free from adhesive residues and that the bond is consistent with no bubbles.

GENERAL

- This information is subject to change due to continuous improvement.

FOR THE BEST RESULTS

- Make sure all specifications and instructions are followed carefully.
- Use only adhesives recommended by adhesive manufacturer.
- Contact your Tarkett representative if unsure about any part of the installation.

If any doubts or clarifications should be needed, please contact your local Tarkett representative for further information.