MAINTENANCE INSTRUCTIONS

LINOLEUM XF, LINOLEUM XF2 - (ALL RANGES WITH THE EXCEPTION OF LINOLEUM SICURO)

2016

To help protect your floorcovering from varying levels of traffic and also as the first defence against the weather, we strongly recommend that barrier mats be installed at entry points to the building to limit the amount of wet and dry soiling. If maintained correctly, these barrier mats should limit the transfer of foot borne contamination and make the daily cleaning and maintenance programme even easier.

Polish or maintainers should not to be applied to the surface of Tarkett Linoleum products, as the unique UV hardened Terpolymer factory applied surface treatment removes their necessity.

Initial Treatment

- 1. Allow at least 2 days from the completion of the installation of the floorcovering, prior to carrying out any wet cleaning.
- 2. Ensure that all trace of adhesive is removed from the surface of the floorcovering.
- 3. Sweep floor area with a soft broom or preferably a dust control mop.
- 4. Depending on the level of site soiling after the installation is complete, it may be necessary to scrub the floor clean, prior to adopting the daily maintenance regime. Please find the following options.
 - a) Mop clean using SYR Scrubclean system with SS1 neutral PH detergent.
 - b) Scrub floor clean with SYR SS1 using a standard-speed rotary machine fitted with a **red pad** or scrub with a scrubber dryer (combination machine) fitted with a **red pad**.
 - c) Scrub floor clean with SYR SS1 using a standard-speed rotary machine (150 250rpm fitted with a **red pad** or scrub with a scrubber dryer (combination machine) fitted with a **red pad**. If the surface is dull, dry burnish with an ultra high-speed rotary machine (best results 1000rpm) fitted with a **white pad**.

If the flooring is laid in a high risk area, such as some areas in health care applications and if there is a risk of high infection the standard infection control agents such as Chlorclean or Actichlor should be used (with care after discussion with the Cleaning product manufacturer) prior to standard SS1 cleaning fluid.

Routine Maintenance

Non-Mechanical Method



- 1. Sweep floor area with a broom or preferably a dust control mop.
- 2. If soiled: Mop clean using SYR Scrubclean system with SS1 neutral PH detergent. Use a hand held red pad or an edging pad to remove heavier soiling.

It is important to ensure that only the smallest amount of moisture is deposited onto the floorcovering when cleaning, so that the floorcovering surface will dry within 15 - 20 seconds.

Mechanical Method



- 1. Sweep floor area with a vacuum, broom or preferably a dust control mop.
- If soiled: Spray clean with diluted SYR SS1 using an ultra high speed rotary machine fitted with a white pad.



MAINTENANCE INSTRUCTIONS

LINOLEUM XF, LINOLEUM XF2 - (ALL RANGES WITH THE EXCEPTION OF LINOLEUM SICURO)

2016



Non-Mechanical Method



- 1. Sweep floor area with a broom or preferably a dust control mop.
- Mop clean using SYR Scrubclean system with SS1 neutral PH detergent. Use a hand held red pad or an edging pad to remove heavier soiled areas.

Mechanical Method



- 1. Sweep floor area with a vacuum, broom or preferably a dust control mop.
- 2. Spray clean with diluted SYR SS1 using an ultra high speed rotary machine (1,000rpm) fitted with a **white pad.**

Periodic Maintenance



- * It is possible to periodically clean Linoleum xf using SYR Scrunge
- Clean floor area with a vacuum, broom or preferably a dust control mop
- Scrub floor clean with SYR SS1 using a standard-speed rotary machine (150 250rpm) fitted with a red pad or scrub with a scrubber dryer (combination machine) fitted with a red pad. If the surface is dull, dry burnish with an ultra high-speed rotary machine (best results 1000rpm) fitted with a white pad.

Dry burnishing is an efficient method for limiting scuffmarks and also restores the floors surface (if light scratching has become visible). It is best to dry burnish immediately after the floorcovering has been machine scrubbed. Dry burnishing greatly reduces renewed soiling. Use an ultra high-speed rotary machine (best results 1000rpm) fitted with a **white pad.**

Cleaning & Maintenance

Stairs - Non-Mechanical



- 1. Sweep risers with a broom or dust control cloth.
- 2. Clean treads by vacuuming or use a soft broom to sweep across the width of the stair.
- 3. Mop clean using SYR Scrubclean system with SS1 neutral PH detergent. Use a hand held **white pad** or an edging pad to remove heavier soiled areas.

Mechanical Method

Stairs - Mechanical (For Larger Applications)



- 1. Sweep risers with a broom or dust control cloth.
- 2. Mop clean using SYR Scrubclean system with Scrubclean Solution detergent neutral PH detergent.

